

Point level detection



## **Product highlights**

- Save detection of liquids, bulk-solids and powders
- Short immersion length
- Excellent cleanability
- Ability for differentiation between foam and liquid
- Not sensitive to adherent or sticky media
- Status signaling by bright, blue LED
- Compact stainless steel housing, sealed up to IP69K

Measures media with DC-values >1.5 (Dielectric Constant)

#### **User benefits**

- One sensor for all applications
- Less disturbance of process
- Safe process with less downtime
- Visual observation of process
- Long life time even in wash-down areas









Housing		Reverse polarity	<ul><li>Yes</li></ul>
Style	<ul><li>Compact design</li></ul>	protection	
Dimension	Refer to dimensional drawings (page 4 f.)	Power-up time	< 2 s
Material	<ul> <li>Stainless steel</li> </ul>	Output signalization	
Electrical connection		Switching polarity	PNF NPN
Connector variants	M12, 4 pin, polycarbonate	Current rating	■ 20 n
Cable outlet	<ul><li>M12, 4 pin, stainless steel</li><li>5 m, 4-wire, PVC</li></ul>	Short circuit protection	<ul><li>Yes</li></ul>
Cable outlet	5 III, 4-wire, PVC	Voltage drop	PNF
Ambient conditions			NPN
Operating temperature	■ -40 85 °C	Off leak current	• ± 10
range Storage temperature	■ -40 85 °C	Switching logic	<ul><li>Norr</li></ul>
range	-40 65 C		<ul><li>Non</li></ul>
	< 98 % RH, condensing	Sensor performance	
Protection class	■ IP67	Repeatability	• ±1
(IEC 60529)	<ul> <li>IP69K (with appropriate cable)</li> </ul>	Hysteresis	■ ±1
Vibration	■ IEC 60068-2-6	Response time	• 0.1
	GL Test 2	Damping	• 0.0
Process connection		Factory settings	
Connection variants	<ul> <li>Refer to dimensional drawings (page 4 f.)</li> </ul>	Switching range (die-	<b>•</b> < 75
Mounting position	<ul><li>Any (top, bottom, side)</li></ul>	lectric constant DC)	
Wetted parts material	<ul> <li>PEEK Natura</li> </ul>	Damping	• 0.1
	AISI 316L (1.4404)	Compliance and app	rovals
Surface roughness	<ul><li>AISI 304 (1.4301) (optional)</li><li>Ra &lt; 0.8 µm</li></ul>	EMC Immunity	■ EN
wetted parts	- Ra < 0.6 μm	EMC Emission	■ EN
**************************************		Explosion protection	<ul><li>ATE</li></ul>
Process conditions	- Defeate table (page 2.f.)		<ul><li>ATE</li></ul>
Process temperature	Refer to table (page 2 f.)	0.64	<ul><li>ATE</li></ul>
Process pressure	Refer to table (page 2 f.)	Safety	• cUL
Power supply		Hygiene	■ Refe
Voltage supply range	■ 12 30 V DC	Railway	■ EN
Current consumption	<ul> <li>25 mA tvp 50 mA max.</li> </ul>	Marine	Refe

protection	
Power-up time	■ < 2 s
Output signalization	
Switching polarity	PNP NPN
Current rating	<ul><li>20 mA max.</li></ul>
Short circuit protection	■ Yes
Voltage drop	<ul> <li>PNP: (+Vs -1.5 V) ± 0.5 V, Rload = 10 kΩ</li> <li>NPN: (+1.5 V) ± 0.5 V, Rload = 10 kΩ</li> </ul>
Off leak current	<ul> <li>± 100 μA max.</li> </ul>
Switching logic	<ul><li>Normally open (NO)</li><li>Normally closed (NC)</li></ul>
Sensor performance	
Repeatability	■ ± 1 mm
Hysteresis	• ± 1 mm
Response time	■ 0.1 s typ. (0.15 ± 0.05 s)
Damping	■ 0.0 10.0 s (adjustable)
Factory settings	

< 75 % (DC > 2)

Refer to table (page 3)

Refer to table (page 3)

EN 50155

 EN 61326 (installed in a metal tank) EN 61326 (installed in a metal tank) ATEX II 1 G Ex ia IIC T4/T5 ATEX II 1 D Ex ta IIIC T100 °C Da ATEX II 3 G Ex nA II T4/T5 cULus Listed, Class 2, E365692


■ 0.1 s



# Point level detection


Process cond	itions					
Туре	Process connection		Process temperature	Process pressure	Process temperature max.	Process pressure @ Process
			continuous Tamb < 50 °C		temporary t < 1 h Tamb < 50 °C	temperature max. temporary
		BCID	°C	bar	°C	bar
LBFS-xx1xx.x	G 1/2 A ISO 228-1	G07	-40 115	-1 100	135	-1 100
LBFS-xxGxx.x	G 1/2 A ISO 228-1 with coo- ling neck, not applicable for mounting with ZPW1-7x1	G07	-40 150	-1 100	N/A	N/A
LBFS-xxAxx.x	G 1/2 A DIN 3852-E, NBR gasket	G51	-40 115	-1 100	135	-1 100
LBFS-xxBxx.x	G 1/2 A DIN 3852-E, FKM (Viton®) gasket	G51	-40 115	-1 100	135	-1 100
LBFS-xx4xx.x	G 1/2 A hygienic	A03	-40 115	-1 10	135	-1 5
LBFS-xxKxx.x	G 1/2 A hygienic, length 82 mm	A03	-40 115	-1 100	135	-1 100
LBFS-xxLxx.x	G 1/2 A hygienic, sliding connection, length 250 mm	A03	-40 200	-1 5	N/A	N/A
LBFS-xx5xx.x	G 1/2 A ISO 228-1 for reverse assembly (in-shell thread)	T10	-40 85	-1 100	135	-1 100
LBFS-xx2xx.x	G 3/4 A ISO 228-1	G10	-40 115	-1 100	135	-1 100
LBFS-xx3xx.x	G 1 A ISO 228-1	G11	-40 115	-1 100	135	-1 100
LBFS-xxNxx.x	1/2-14 NPT	N02	-40 115	-1 100	135	-1 100
LBFS-xxMxx.x	1/2-14 NPT with cooling neck	N02	-40 150	-1 100	N/A	N/A
LBFS-xx6xx.x	3/4-14 NPT	N03	-40 115	-1 100	135	-1 100
LBFS-xx7xx.x	M18x1	M11	-40 115	N/A	N/A	N/A
LBFS-xxExx.x	G 1/2 A DIN 3852-E, FKM (Viton®) gasket with cooling neck	G51	-40 150	-1 100	N/A	N/A

# Process connection type 1, 2, 3, 4, 6, 7, A, B, G, K, M, N, E



# Process connection type L (sliding connection)

		P	rojec	ting	lengt	h min	. (mn	n)
	200		25	35	50	65	90	145
	190		20	35	45	65	90	140
	180		20	30	45	60	85	140
0	170		20	25	40	55	85	135
Process temperature (°C)	160	25		25	35	55	80	130
atur	150			20	25	50	75	130
per	140			20	30	45	75	125
em	130		-			45	70	120
ss t	120				20	40	65	115
900	110				20	25	60	110
P	100		No			30	55	105
	90		limit	ation		25	50	100
	80					20	45	95
	70						35	85
	60						35	65
		35	40	45	50	55	60	65
		Ambient temperature (°C)						





	1	Park Sand	1 -1 -		
P0	ını	leve	dei	rect	เดท

Туре	Process connection	BCID	EN 1935/2004 EN 10/2011 EN 2023/2006	FDA	3-A	EHEDG EL-Class I	DNV	GL	Lloyd's Register	ccs	WHG (overfill, leakage)	
_BFS-xx1xx.x	G 1/2 A ISO 228-1	G07										
BFS-xxGxx.x	G 1/2 A ISO 228-1 with cooling neck	G07										
BFS-xxAxx.x	G 1/2 A DIN 3852-E, NBR gasket	G51										
_BFS-xxBxx.x	G 1/2 A DIN 3852-E, FKM (Viton®) gasket	G51						•				
LBFS-xx4xx.x	G 1/2 A hygienic	A03	•	-		•	-	•		-	•	
LBFS-xxKxx.x	G 1/2 A hygienic, length 82 mm	A03										
LBFS-xxLxx.x	G 1/2 A hygienic, sliding connection, length 250 mm	A03	•	•								
LBFS-xx5xx.x	G 1/2 A ISO 228-1 for reverse assembly (in-shell thread)	T10					•	•		٠		
LBFS-xx2xx.x	G 3/4 A ISO 228-1	G10										
LBFS-xx3xx.x	G 1 A ISO 228-1	G11										
LBFS-xxNxx.x	1/2-14 NPT	N02										
LBFS-xxMxx.x	1/2-14 NPT with cooling neck	N02										
LBFS-xx6xx.x	3/4-14 NPT	N03										
LBFS-xx7xx.x	M18x1	M11										
LBFS-xxExx.x	G 1/2 A DIN 3852-E, FKM (Viton®) gasket with cooling neck	G51										

Note: Information on product characteristics may relate to defined product options

The requirements of the respective 3-A Sanitary Standard will be only fulfilled in combination with appropriate mounting accessories. Those are marked with the 3-A logo.

The EHEDG certification is only valid in combination with appropriate mounting accessories.

Those are marked with the "EHEDG Certified" logo

#### ATEX II 1 G Ex ia IIC T4/T5

Internal inductance

Maximun values (for barrier selection) (1)

Ui: 30 V DC

Ii: 100 mA

Pi: 0.75 W

Internal capacitance

Ci: 43 nF

Temperature class T1...T4: -40 < Tamb < 85 °C

Li: 10 μH

■ T1...T5: -40 < Tamb < 74 °C

# ATEX II 1 D Ex ta IIIC T100 °C Da

Voltage supply range • 30 V DC max.

Temperature class T100 °C: -40 < Tamb < 85 °C

Protection class of PP67

cable accessory

# ATEX II 3 G Ex nA II T4/T5

Voltage supply range • 30 V DC max.

Temperature class T1...T4: -40 < Tamb < 85 °C

T1...T5: -40 < Tamb < 74 °C</p>



# Point level detection

#### Field of application

CleverLevel® LBFS is designed for level detection in tanks and dry-run protection of pumps by empty pipe monitoring. It detects liquid, pasty or oily media, but also solid-bulk materials like flour or plastic granulate. The LBFS is capable of media differentiation by distinguishing the specific properties, such as oil, wate, foam and liquid.

Reliable performance is assured in any mounting position (from top, bottom or side). Depending on the desired process connection, different mounting options are available. Corresponding mounting aids and adaptors for conventional process connections are available as an accessory.


Two parallel switching outputs are available as Normally Open (NO) and Normally Closed (NC) which is defined by PN or NPN polarity when placing the order.


CleverLevel® LBFS in its default configuration covers a major part of potential applications. Where customer-specific configuration is require because of difficult media (e. g. foamy or adhering), the interface pr gramming tool FlexProgrammer 9701 allows for easy parameterization of the optimum switching points by convenient teach-in functionality. The measured data can be visualized on a PC for further parameter adjustment, for example time constant of a damping function and inverted switching output logic.


#### Measuring principle

An electrode inside the sensor tip builds a capacitor together with the surroundings. The medium with its dielectric constant (DC value) is defining the capacitance value. A resonance circuit is created in combination with a coil in the sensor head. Switching signal tripping is according to the measured resonance frequency and the programmed trigger thresholds.

# **Dimensional drawings**









LBFS-xx1xx.x

G 1/2 A ISO 228-1 LBFS-xxGxx.x

G 1/2 A ISO 228-1 with cooling neck LBFS-xxAxx.x LBFS-xxBxx.x G 1/2 A DIN 3852-E, NBR / FKM (Viton®) gasket






LBFS-xx4xx.x

G 1/2 A hygienic

LBFS-xxExx.x G 1/2 A DIN 3852-E, FKM (Viton®) gasket, with cooling neck




# **Dimensional drawings**




LBFS-xxKxx.x


G 1/2 A hygienic, length 82 mm




LBFS-xxLxx.x

G 1/2 A hygienic, sliding connection, length 250 mm







# LBFS-xx5xx.x


G 1/2 A ISO 228-1 for reverse assembly (in-shell thread)


# LBFS-xx2xx.x


G 3/4 A ISO 228-1

## LBFS-xx3xx.x

G 1 A ISO 228-1







#### LBFS-xxNxx.x

1/2-14 NPT

# LBFS-xxMxx.x

1/2-14 NPT with cooling neck


# LBFS-xx6xx.x

3/4-14 NPT



Point level detection


# **Dimensional drawings**



LBFS-xx7xx.x M18x1



Connector M12



LDI O AZAAA.

Cable outlet

# **Electrical connection**

## Terminal assignment



Connector M12	
1	
2	

3

2 Cable outlet
Brown
White
Blue
Black

Function + Vs


Normally closed (NC)

0 V

Normally open (NO)

# Switching characteristic

Switching logic



**PNP** 


Normally closed (NC)












Normally open (NO)




LED

PNP



NPN





# Point level detection

Ordering code			
		LBFS - X X	x   x   x   .   x
Type  Level switch  Compliance and approvals  Standard  ATEX II 1 G Ex ia IIC T4/T5 (2)  ATEX II 1 D Ex ta IIIC T100 °C Da  ATEX II 3 G Ex nA II T4/T5  ATEX II 1 G Ex ia IIC T4/T5 and ATEX II 1 D Ex ta IIIC T100 °C cULus Listed, Class 2, E365692	Da (2)	LBFS 0 1 2 2 3 4 4 A	
EAC (TR CU 020/2011)		В	
Electrical connection  Connector M12, 4 pin, polycarbonate (with LED)  Cable outlet 5 m, 4-wire, PVC (3)  Connector M12, 4 pin, stainless steel (without LED)  Process connection  G 1/2 A ISO 228-1  G 1/2 A ISO 228-1 with cooling neck  G 1/2 A DIN 3852 form E, NBR gasket  G 1/2 A DIN 3852 form E, FKM (Viton®) gasket	(BCID) (G07) (G07) (G51) (G51)	1 2 3	
G 1/2 A DIN 3852 form E, FKM (Viton®) gasket, with cooling ne G 1/2 A hygienic G 1/2 A hygienic, length 82 mm G 1/2 A hygienic, sliding connection, length 250 mm G 1/2 A ISO 228-1 for reverse assembly (in-shell thread) (4) G 3/4 A ISO 228-1 G 1 A ISO 228-1 1/2-14 NPT 1/2-14 NPT with cooling neck 3/4-14 NPT	ck (G51) (A03) (A03) (A03) (T10) (G10) (G11) (N02) (N02) (N03)		E 4 K L 5 2 3 N M 6 7
M18x1 Wetted parts material	(M11)		1
AISI 304 (1.4301) (available for "Process connection" 1, 2, 3, 5, AISI 316L (1.4404)	6, 7)		1 2
Switching polarity PNP NPN			1 2
Configuration Factory setting Customer-specific			0 C

(2) The isolating barrier PROFSI3-B25100-ALG-LS is recommended with PNP switching polarity for Ex ia IIC (please refer to accessories, page 10)

(3) Ambient temperature: -25 ... 70°C (if the cable is unmoved) -5 ... 70°C (if the cable is moved)

Bending radius min.: r≥ 10 mm

(4) Including gasket ZPX3-14B0 (glass/aramide fiber with NBR)



# Accessories

# Industrial weld-in sleeves for LBFS-xx1xx.x, (BCID: G07)

Ordering code

Thick wall tank - AISI 304 (1.4301)

ZPW1-711



Thick wall tank - AISI 316L (1.4404)

ZPW1-721



# Hygienic adapters for LBFS-xx4xx.x, LBFS-xxKxx.x, LBFS-xxLxx.x (BCID: A03)

















1	1	7	13	-
-	1	1	9	1
	1		/	









Description	Ordering code
ocsonption	Ordering code

Clamp,	
DIN 32676 DN 25, DN 40	
ISO 2852 DN 25, DN 38	ZPH3-3213

DIN 32676 DN 50	
ISO 2852 DN 51	ZPH3-3216

DIN 11851	
DN 25	ZPH3-3221
DN 40	ZPH3-3224
DN 50	ZPH3-3225

SMS 1145	
DN 51	ZPH1-3236

Varivent® Type N	ZPH3-324E	
Varivent® Type F	ZPH3-344F	

DIN 11864-1-A	
DN 40	ZPH3-3254
DN 50	ZPH3-3255



# Accessories

# Hygienic weld-in sleeves for LBFS-xx4xx.x, LBFS-xxKxx.x, LBFS-xxLxx.x (BCID: A03)





Description

Tanks, with leak detection port

Ordering code ZPW3-321





Thin wall tanks

ZPW3-322



Tanks, pipes

ZPW2-324



Pipe with collar DN 25 ... DN 50 DN 65 ... DN 150

ZPW2-326 ZPW2-327

# Threaded adapters for LBFS-xx4xx.x, LBFS-xxKxx.x, LBFS-xxLxx.x (BCID: A03)



Description
Vibronic level switch replacement
EH FTL G 3/4 A
VS G 3/4 A
EH FTL G 1 A
VS G 1 A

Ordering code

ZPH1-32BA ZPH1-32BC ZPH1-32CB ZPH1-32CD



Industrial G 1 A G 1 1/2 A G 2 A

ZPI1-32B ZPI1-32D ZPI1-32E



Level measurement CleverLevel® LBFS Point level detection

## Accessories

# Spare parts



Description

Ordering code

G 1/2 A gland nut for LBFS-xxL2x.x with sliding ZPX1-008 connection (BCID: A03)

Compression ring kit for LBFS-xxL2x.x with sliding connection (BCID: A03)

ZPX1-006



Gasket for LBFS-xx5xx.x for reverse assembly ZPX3-14B0 (BCID: T10)

#### Interfaces



Description

Ordering code

FlexProgrammer 9701 Programming kit for sensor parameterization. The set contains a FlexProgrammer, all cables needed, carrying strap and the FlexProgrammer software on a CD.

9701-0001



ATEX isolating barrier for LBFS-xxxx1.x, LBFS-xxxx4.x with PNP switching polarity for Ex ia IIC

PROFSI3-B25100-ALG-LS

For more detailed information please refer to the applicable product data sheet.

Installation and update

**English** 



## Installation of FlexProgram PC software

## WARNING!

Do not connect the FlexProgrammer 9701 to your PC before the installation of the FlexProgram software.

- 1) Quit all programs and insert the CD.
  - a) The CD will start an automatic installation.
  - If your autorun function has been disabled the installation should be done manually.
    - Select the "FlexProgram\_Package" folder at the CD and run the .exe-file.
- During installation you will be prompted for
  - a) User rights for the software
  - b) Folder name for the FlexProgram installation.
- 3) After the installation the FlexProgram will start automatically.

## Charging of battery of the FlexProgrammer 9701

- 1) Connect the FlexProgrammer 9701 to your PC to ensure that the battery will be recharged.
- 2) The battery will be discharged if the FlexProgrammer 9701 is not connected to a PC for some time.
- 3) It takes up to 16 hours to fully charge the FlexProgrammer 9701.
- 4) When receiving the FlexProgrammer 9701 it may be necessary to charge it before use.

#### The FlexProgrammer 9701 kit

The FlexProgrammer 9701 is the dedicated configuring tool for a wide range of Baumer products.

The kit consists of

- FlexProgrammer 9701
- CD with the FlexProgram PC software
- USB cable
- Cable with 2 alligator clips
- Cable from FlexProgrammer to M12 plug for TE2
- Cable from FlexProgrammer to M12 Plug for various instruments such as LBFS and PBMN

#### FlexProgrammer 9701 menu

Press (2) and (3) simultaneously to enter the FlexProgrammer 9701 menu containing e.g. Teach-In and Autozero functionalities.

Press O or to browse the menu

Press ( ) to access current menu point

Press ( to return to previous menu


#### Reset

Press **●** and **●** simultaneously for 5 seconds to reset the FlexProgrammer 9701.

# Store configuration to FlexProgrammer 9701

It is possible to store configuration data from a wide range of Baumer products included in the FlexProgram PC software (except AFI4/AFI5) to the FlexProgrammer 9701 for remote configuration.

- Connect the FlexProgrammer 9701 to the USB port, open the FlexProgram PC software and select the product.
  - Note: Do not connect the product.
- Press the icon "store to device" and click "yes" to the following screen:



- Once finshed a screen shows "Configuration is successful finished".
- Go to the field and connect the FlexProgrammer 9701 to the instrument and press
- The FlexProgrammer 9701 display will show "Download 'instrument type'".
- 6) Once done the display shows "Download Success".



# Installation of Flexprogram software

English

# **Downloading FlexProgram and Firmware**



Downloading of the FlexProgram PC software and various instrument firmware can be done from the Baumer home page.

## FlexProgram:

www.baumer.com > Services > Downloads > Software - FlexProgram Package - B-...

#### FlexProgrammer 9701:

www.baumer.com > Services > Downloads > Software - FlexProgrammer Firmware...

# Baumer instrument:

www.baumer.com > Services > Downloads > Software - "relevant instrument" Firmware, e.g. CombiPress PFMx Firmware ver

Click on the desired download in the "Language" box.

Download and save the file on your PC in a selected directory e.g. on your desktop.

If it is a ZIP-file, please unzip the downloaded file to a selected directory, e.g. on your desktop.

#### Installation and update of the FlexProgram software

Open the file with the downloaded, unzipped file, click on the "FlexProgram software package B...exe" and follow the instructions and the FlexProgram will automatically be installed on your PC.


The Basic FlexProgram Package includes drivers for the FlexProgrammer 9701 and all the instruments, that are programmable with this software. A new version will automatically overwrite older versions and you are able to work with the new version as soon as it is installed.

# Update the FlexProgrammer 9701 and instrument Firmware


Connect the instrument to the FlexProgrammer 9701 and the Flex-Programmer 9701 to your PC.

Choose the relevant instrument from the list to the left.

Press "View" and click on "Project window"



A project tree appears



Go to page 3 for FlexProgrammer 9701 firmware update Go to page 4 for instrument firmware update



Installation of Flexprogram software

#### English

#### **Updating the FlexProgrammer 9701 firmware**



Right click on Flexprogrammer 9701

and this selection box will appear

Click on Firmware download

and this window will appear

Press Get versions

and the hardware and software version number will be shown. If your software version has a lower version number than the newest version of the FlexProgrammer 9701 firmware, please update the FlexProgrammer 9701.

Note: In case the software is corrupt and shows an error message please close and reopen the FlexProgram.


Skip the step Get versions and go directly to Firmware download.

#### Firmware download

Press and find and select the unzipped file (.txt file) in your directory and then press stat

Update will now take place.

It may take several minutes before the update is completed.









mware download			
Firmware file			
			( )
	Start )	Albort	



Installation of Flexprogram software

English

# **Updating of instrument firmware**



Right click on the connected instrument e.g. [6] DFON

and this selection box will appear

Click on Firmware download

and this window will appear

Press Get versions

and the version number will be displayed.

If your software version has a lower version number than the newest version of the instrument firmware, please update the instrument.

Note: In case the software is corrupt and shows an error message please close and reopen the FlexProgram.

Skip the step Get versions and go directly to Firmware download.


#### Firmware download


Press and find and select the unzipped file (.txt file) in your directory and then press start

Update will now take place.

It may take several minutes before the update is completed.

When the update of the instrument firmware has been finished successfully the text to the right will be displayed.









lutput:	
	Firmware download successful

#### Baumer A/S

Runetoften 19 8210 Aarhus V Denmark

Phone: +45 8931 7611