



**STOP  
CLIMBING BINS!**

Automated Level  
Measurement  
**BINMASTER.**

402-434-9102      [www.binmaster.com](http://www.binmaster.com)      800-278-4241

## New BinMaster SmartBob HM Features Horizontal Mounting



BinMaster introduces an innovative weight-and-cable based level sensor for mounting on the side of the bin, tank or silo. The SmartBob HM - for horizontal mount - can be used when it is not possible to install the sensor on the top of the bin.

The SmartBob HM level sensor works like an automated tape measure, but eliminates the need to climb bins for manual measurements to reduce the risk of accidents in the workplace. Precise level measurements are taken at pre-determined time intervals at a location directly below the probe to continuously monitor the inventory of material inside of the bin.

POB 1778 Greer, SC 29652  
414 West Poinsett Street Greer, SC 29650  
[mike@traskinst.com](mailto:mike@traskinst.com)

Ph: 864-848-3993

[www.traskinstrumentation.com](http://www.traskinstrumentation.com)

Fax: 864-848-9569

- Ideal for situations when sensor cannot be mount on top of bin
- Rigid extension custom-made from 12' to 36' long
- Installs on the side of the bin through a 4' opening
- Level data sent directly to control console or eBob software installed on a PC
- Listed for Class II, Groups E, F, & G; safe to use in hazardous locations

If you need accurate bin level measurement and cannot top mount your sensor, the SmartBob HM may be the solution you're looking for!

Call Todd Peterson at 402-434-9102 or [email](#) Todd to discuss your needs.

In a hurry? Use the [Sales & Tech Support Form](#) and we'll get right back to you.

POB 1778 Greer, SC 29652  
414 West Poinsett Street Greer, SC 29650  
[mike@traskinst.com](mailto:mike@traskinst.com)

Ph: 864-848-3993

[www.traskinstrumentation.com](http://www.traskinstrumentation.com)

Fax: 864-848-9569