


Technical Bulletin: How to Wire Flexible Current Transformer to Panel Meter



Your Sensor Solution Source
414 Poinsett St., Greer, SC 29650
(864) 848-3993 Fax: (864) 848 9569