



VIRTU™

Ultrasonic Dual-Level Sensors



The next generation of the Virtu ultrasonic sensor family stays true to being a low-cost application solution.

The newest edition of the Virtu™ ultrasonic sensor was developed by Hyde Park to feature pump-in/pump-out functionality.

Virtu's dual-mount body style, with its M18 x 1 threaded snout 0.89" long and a 1.49" rectangular body for a total length of only 2.38", and tough VALOX® housing make it not only ideal for many OEM applications but also an unfailing performer for an array of packaging applications, including food and beverage. Available in cable or connector style, Virtu is the first sonic compact sensor to offer a dual mounting feature. It operates on 12 to 24 VDC and provides either a sinking (NPN) or a sourcing (PNP) output. Virtu also has teach-in window capability, and no downtime is required for sensor recalibration when colors, materials, or shapes change.

With protection ratings of NEMA 4X (indoor use only) and IP67, this CE certified sensor is resistant to dust, 100% humidity, most acids and bases, and high pressure washdowns that often leave water buildup on the sensing face. This sleek sensor is virtually impervious to the ef-

fects of splashing food, caustic cleaning solutions, and changing light conditions or colors. Shielding and filtering make the fully encapsulated sensor resistant to radiated or conducted energy.

Operation

The Dual Level VM series is a self-contained, pulse-echo, proximity sensing device that both transmits and receives sonic energy within a 508 mm (20") maximum sensing range. Operating on 12 to 24 VDC, and employing the latest piezoelectric and microprocessor technology, Virtu sensors detect only those designated objects within a set "window" and ignore all surrounding sonic interference.

Prior to operation, a simple and easy "teach" function is used to set the sensing window limits through either a remote or inline cable push-button. A near and far limit for a desired sensing window can be set anywhere within the sensing range and may be set to either encompass the full sensing range or be as small as 6 mm (0.25").

When selecting by model number from several factory-programmed, dual-limit parameters (near limit and far limit), the sensor can be set up to perform an on/off latch control function.

The sensor is equipped with a two-color status LED to show the state of the output. When the

- Sensing range of 50.8 mm (2") up to 508 mm (20")
- Dual-mount flat-profile body style and 18 mm barrel
- Pump-in/Pump-out Latch Capabilities
- Rugged duty design for harsh environments
- Simple remote push-button accessory available for teaching of sensing limits
- NEMA 4X (indoor use only), IP67
- CE certified

output is active, the LED is amber, regardless of whether the output is normally open or closed. When the output is not active, the LED is green. The LED also serves to show the sensing status of the sensor. With a normally open output and an object in the sensing window, the LED will be amber and switch to green when the object leaves the sensing window, switching off the output. With a normally closed output and an object in the sensing window, the LED will be green and switch to amber when the object leaves the sensing window, switching on the output.

Setting the Window Limits

Before operating the sensor, you should teach the sensor the sensing window. The sensing window is the distance between the near and far limits. To teach the limits, press and hold the push-button. The LED fast flashes amber and then after holding the push-button for 3 seconds, the LED slowly flashes green indicating the sensor is in teach mode. Release the push-button, and the LED continues slowly flashing green indicating the sensor is waiting for the first limit. Place a target at either limit, and press and release the push-button. While the push-button is pressed with a target present, the LED turns amber indicating a valid echo is being detected. After teaching the sensor the first limit successfully, the LED slowly flashes amber indicating the sensor is waiting for the second limit. Place a target at the second limit, then press and release the push-button. While the push-button is pressed with a target present, the LED turns amber indicating a valid echo is being detected. After teaching the sensor the second limit, the two limits are saved in non-volatile memory. The LED fast flashes green for 3 seconds to indicate the limits were successfully saved. The limits can be set in either order.

To teach the default window of 25.4 mm (1.0"), while the sensor is in teach mode requesting the first limit (LED slowly flashing green), place a target parallel to the sensor face at the center of the desired window. Press and release the push-button twice in succession within one second. The LED fast flashes green indicating the limits were successfully saved. This sets the limits 12.7 mm (0.5 in.) in front of and behind the front surface of the target.

If not using an optional push-button, the process is similar. The white teach wire (pin 2) can be grounded to the blue DC return wire (pin 3) to simulate the pushing of the button. All LED indications and the teach sequence is identical to the previously detailed process.

While setting either limit, if no echo is detected, the LED fast flashes green and amber indicating no object is detected. After 5 seconds, the sensor resumes operation with the old limits. If either limit is not set in 30 seconds, a limit timeout occurs, the LED flashes green and amber for 3 seconds indicating the error. The sensor then resumes operating with the old limits.

How Does It Work?

During teach and operation, the Virtu sensor continually and accurately measures the elapsed time from the first pulse echo received after each pulse transmission. The transmitted pulse begins a time clock to register the elapsed time of the first received pulse echo. Given the elapsed time, the sensor software calculates the distance traveled out to the object or surface and back to the sensor, using the formula $D = TV_s/2$, where: D = distance from the sensor to the object; T = elapsed time between the pulse transmission and its first received echo; V_s = the velocity of sound, approximately 335 meters (1100 feet) per second.

During operation, the calculated distance (D) between the sensor and the object is compared to the distances associated with the window limits. These limits are shown in the illustration as D_{wi} and D_{wo} . If D is within these limits, an output is activated or deactivated, depending on whether normally open or normally closed. The output remains in such state until the echo does not return or it returns from outside the window limits.

Level-Control Functions


The level-control output can be configured for one of different operating functions. Using the Model Reference Guide, the sensor can be selected to perform either a pump-in level-control function or pump-out level-control function.

Pump-in Level Control

When the level moves beyond the far limit, the sensor level control output switches state and latches, starting a pump-in process. The sensor level control output does not change state until the level moves back beyond the near limit to stop the pumping or filling process.

Pump-out Level Control


When the level moves beyond the far limit, the level control output switches state and latches, stopping a pump-out process. The sensor level control output does not change state until the level moves back beyond the near limit to restart the pump-out process.




Electrical Wiring

The sensor cable must be run in conduit, free of any AC power or control wires.


NPN Cable Style Wire




PNP Cable Style Wire



NPN Discrete Micro Connector Style




PNP Discrete Micro Connector Style




Output Style

NPN Output




PNP Output




Output Type

Pump-in Level Control



Pump-out Level Control




Beam Plots

The following plots, developed from data collected at 20°C, zero air flow, defines the boundaries and shape of the sonic beam for the Virtu series sensors.

The boundaries were established using a 10 cm x 10 cm (3.94" x 3.94") "target" positioned parallel to the sensor face. The plot for each sensor series is valid for targets equal to or larger than 10 cm x 10 cm. Beam boundaries are determined by moving the large flat target into the beam while the plane of the target is held perpendicular to the beam axis.

In each sensor series, the plot extends from the end of the "deadband" on the left to the end of the sensing range on the right. The sensor is illustrated in the middle left margin.


These and other plots are available from Hyde Park upon request.



Dimensions


Quick Disconnect Style

(VALOX® Plastic) VM1-XXX-X




Cable Style

(VALOX® Plastic) VM1-XXX-X




Quick Disconnect Style

(VALOX® Plastic) VM18-XXX-X



Cable Style

(VALOX® Plastic) VM18-XXX-X



Model Reference Guide - VM Dual-Level Series

Use the guide below to ensure the correct model number is specified for the application. Please note that not all sensor model combinations are available.

EXAMPLE MODEL:

VM 18- P PI 0 001 - Q

Ultrasonic Virtu Dual-Level Series

Model Type

- 1... Dual-mount, flat-profile
- 18... 18 mm barrel

Output Type

- N... NPN sinking output
- P... PNP sourcing output

Dual Level Output Style

- PI... Pump In Latch
- PO... Pump out Latch

Output State and LOE

- 0 - NO, Output OFF at loss-of-echo and OFF at power up
- 1 - NO, Output ON at loss-of-echo) and ON at power up
- 2 - NO, Output HOLD at loss-of-echo and OFF at power up
- 3 - NO, Output HOLD at loss-of-echo and ON at power up
- 4 - NO, Output OFF at loss-of-echo and ON at power up

Response Time

- 0 - Standard 150 ms (30 cycles) On, 150 ms (30 cycles) Off, 1 sec (200 cycles) Loss-of-Echo
- 1 - 200 cycles On / 200 cycles Off, 200 cycles Loss-of-Echo
- 2 - 200 cycles On / 400 cycles Off, 200 cycles Loss-of-Echo
- 3 - 2 cycles On / 2 cycles Off
- 4 - 4 cycles On / 4 cycles Off

Functionality


- 00 - Standard functionality, +/- 0.50" (12.7 mm) default window
- 01 - +/- 0.25" (6.35 mm) default window

Connection Types


- ...No designator indicates 3m (10') cable style connection
- Q... Quick disconnect – 4 pin "micro" connector

Accessories

AC130 Straight, M12 micro, 4-conductor, connector/cable assembly, 5 m (16') (for barrel and flat-profile micro sensors)



PB100 In-line accessory push-button for teaching window limits (for Virtu series sensors).



AC132 Right-angle, M12 micro, 4-conductor, connector/cable assembly, 5 m (16') (for flat-profile connector-style sensors)

General Specifications

Sensing [$T_A = 20^\circ\text{C}$ (68° F)]

Sensing Range:

50 mm (2") to 508 mm (20")
(large flat objects)

Sonic Frequency: 300 kHz

Minimum-size Detection:

2.5 mm (0.098") diameter rod or 1.0 mm (.039")
bar at a distance of 200 mm (8")

Note: Smaller object may not be detected at
closer distances

Maximum Angular Deviation:

$\pm 5^\circ$ on a 100 mm x 100 mm (4" x 4")
flat target at a distance of 508 mm (20")

Sonic Cone Profile:

see beam plot on page 3-3

Limit Position Accuracy:

± 1.6 mm (0.062") max.

Repeatability:

± 0.7 mm (0.027") or better

Loss of Echo:

Echo Loss off after 200 cycles

Power Requirements

Supply Voltage:

12VDC to 24VDC $\pm 10\%$, regulated supply

Current Consumption:

40 mA max. (excluding load)

Power Consumption:

1.0 W max. (excluding load)

Output

Sinking Output (NPN Model VM1-NXX):

Maximum on-state voltage: 0.75 V @ 100 mA

Maximum load current: 100 mA

Maximum applied voltage: 30 VDC

Sourcing Output (PNP Model VM1-PXX):

Maximum on-state voltage drop: 1.10 V @
100mA

Maximum load current: 100mA

Output voltage: $V_{\text{Supply}} - 1.10$ V @ 100mA

Input-Teach Setup

Contact Closure (push-button) to common. Internal
115KW pull-up to 5V

Input Voltage Range

Setup Input Active 0V to 1V

Setup Input Inactive 2.5V to 5V

Max Voltage without Damage -30V to 30V

Response Time

15.0 ms on/ 15.0 ms off max

Indicators

Green LED: Illuminated if output is off

Amber LED: Illuminated if output is on

Note: Green and Amber LEDs are never illuminated
simultaneously

Connections

Cable style models:

24 AWG, foil shield, lead-free, PVC jacket

4-conductor, 3m (10') long

Connector style models:

12 mm, circular 4-pole, male micro connector

Protection

Power Supply: Current-limited over-voltage, ESD,
reverse polarity

Output: Current-limited over-voltage, ESD, reverse
polarity

Input: Current-limited over-voltage, ESD, reverse
polarity

Environmental

Operating Temperature Range:

-30° to 70°C (-22° to 152°F)

Storage Temperature Range:

-40° to 85°C (-40° to 185°F)

Operating Humidity: 100% non-condensing

Protection Ratings: NEMA 4X (indoor use only), IP67

Chemical Resistance: Resists most acids and
bases, including most food products

Agency Approvals

CE Mark: CE conformity is declared to:
EN60947:1998 (proximity sensors)

EN61010-1 (general safety)

EMC:

FCC 47 CFR Part 15 Class A (USA)

EN5022:1994 / A2:1997 Class A ITE (EU)

VCCI Class A ITE (Japan)

AS/NZS 3548:1995 / CISPR 22 Class A ITE

(Australia)

Declaration of Conformity available upon request

Construction

Dimensions:

Barrel (snout): 18 mm (0.709") x 1 mm-6g thread x
22.23 mm (0.875") long

Flat-profile: 43.74 mm (1.722") x

18 mm (0.709") x

59.69 mm (2.354")

Overall length: 59.69 mm (2.354")

Housing:

Shock and vibration resistant

Dual-mount style: VALOX[®] plastic (FDA
Approved)

18 mm barrel style: PBT

Transducer Face: Epoxy

Sensor Cable: PVC jacketed, black

LED: Polycarbonate

* VALOX[®] is a registered trademark of The General Electric
Co.

Accessories

Model PB100, In-line push-button switch (for
teaching window)

Model AC130, Straight, M12 micro, 4-conductor,
connector/cable assembly, 5 m (16'), for micro-
connector sensors

Model AC132, Right-angle, M12 micro, 4-conductor,
connector/cable

assembly, 5 m (16'), for micro connector sensors

Model AC228, Right-angle bracket

See page 7-1 for accessory photos.

Selection Chart

VM Series Dual Level

Model No.	Power Version 12/24 VDC	Conn. Style		Sensing		Materials			Outputs				Special Features
		Cable	Quick Disconnect			Epoxy	VALOX	PBT	Type				
				Range	Window				NPN sinking	PNP sourcing	Pump-in latch	Pump-out latch	
VM1-NPI0000	■	■		508 mm (20")	Teachable	■	■		■		■		+/- 12.7mm (0.50") default window
VM1-NPO0000	■	■		508 mm (20")	Teachable	■	■		■		■		+/- 12.7mm (0.50") default window
VM1-NPI0000-Q	■		■	508 mm (20")	Teachable	■	■		■		■		+/- 12.7mm (0.50") default window
VM1-NPO0000-Q	■		■	508 mm (20")	Teachable	■	■				■		+/- 12.7mm (0.50") default window
VM1-PPI0000	■	■		508 mm (20")	Teachable	■	■			■	■		+/- 12.7mm (0.50") default window
VM1-PPO0000	■	■		508 mm (20")	Teachable	■	■			■	■		+/- 12.7mm (0.50") default window
VM1-PPI0000-Q	■		■	508 mm (20")	Teachable	■	■			■	■		+/- 12.7mm (0.50") default window
VM1-PPO0000-Q	■		■	508 mm (20")	Teachable	■	■			■	■		+/- 12.7mm (0.50") default window
VM1-NPI0001	■	■		508 mm (20")	Teachable	■	■		■		■		+/- 6.35mm (0.25") default window
VM1-NPO0001	■	■		508 mm (20")	Teachable	■	■		■		■		+/- 6.35mm (0.25") default window
VM1-NPI0001-Q	■		■	508 mm (20")	Teachable	■	■		■		■		+/- 6.35mm (0.25") default window
VM1-NPO0001-Q	■		■	508 mm (20")	Teachable	■	■		■		■		+/- 6.35mm (0.25") default window
VM1-PPI0001	■	■		508 mm (20")	Teachable	■	■			■	■		+/- 6.35mm (0.25") default window
VM1-PPO0001	■	■		508 mm (20")	Teachable	■	■			■	■		+/- 6.35mm (0.25") default window
VM1-PPI0001-Q	■		■	508 mm (20")	Teachable	■	■			■	■		+/- 6.35mm (0.25") default window
VM1-PPO0001-Q	■		■	508 mm (20")	Teachable	■	■			■	■		+/- 6.35mm (0.25") default window
VM18-NPI0000-Q	■		■	508 mm (20")	Teachable	■		■	■		■		+/- 12.7mm (0.50") default window
VM18-NPO0000-Q	■		■	508 mm (20")	Teachable	■		■	■		■		+/- 12.7mm (0.50") default window
VM18-PPI0000-Q	■		■	508 mm (20")	Teachable	■		■	■	■	■		+/- 12.7mm (0.50") default window
VM18-PPO0000-Q	■		■	508 mm (20")	Teachable	■		■	■	■	■		+/- 12.7mm (0.50") default window
VM18-NPI0001-Q	■		■	508 mm (20")	Teachable	■		■	■		■		+/- 6.35mm (0.25") default window
VM18-PPI0001-Q	■		■	508 mm (20")	Teachable	■		■	■		■		+/- 6.35mm (0.25") default window
VM18-PPO0001-Q	■		■	508 mm (20")	Teachable	■		■	■		■		+/- 6.35mm (0.25") default window
VM1-NPI1000	■	■		508 mm (20")	Teachable	■	■		■		■		+/- 12.7mm (0.50") default window
VM1-NPO1000	■	■		508 mm (20")	Teachable	■	■		■		■		+/- 12.7mm (0.50") default window
VM1-NPI1000-Q	■		■	508 mm (20")	Teachable	■	■		■		■		+/- 12.7mm (0.50") default window
VM1-NPO1000-Q	■		■	508 mm (20")	Teachable	■	■		■		■		+/- 12.7mm (0.50") default window
VM1-PPI1000	■	■		508 mm (20")	Teachable	■	■			■	■		+/- 12.7mm (0.50") default window
VM1-PPO1000	■	■		508 mm (20")	Teachable	■	■			■	■		+/- 12.7mm (0.50") default window
VM1-PPI1000-Q	■		■	508 mm (20")	Teachable	■	■			■	■		+/- 12.7mm (0.50") default window
VM1-PPO1000-Q	■		■	508 mm (20")	Teachable	■	■			■	■		+/- 12.7mm (0.50") default window
VM1-NPI1001	■	■		508 mm (20")	Teachable	■	■		■		■		+/- 6.35mm (0.25") default window
VM1-NPO1001	■	■		508 mm (20")	Teachable	■	■		■		■		+/- 6.35mm (0.25") default window
VM1-NPI1001-Q	■		■	508 mm (20")	Teachable	■	■		■		■		+/- 6.35mm (0.25") default window
VM1-NPO1001-Q	■		■	508 mm (20")	Teachable	■	■		■		■		+/- 6.35mm (0.25") default window
VM1-PPI1001	■	■		508 mm (20")	Teachable	■	■			■	■		+/- 6.35mm (0.25") default window
VM1-PPO1001	■	■		508 mm (20")	Teachable	■	■			■	■		+/- 6.35mm (0.25") default window
VM1-PPI1001-Q	■		■	508 mm (20")	Teachable	■	■			■	■		+/- 6.35mm (0.25") default window
VM1-PPO1001-Q	■		■	508 mm (20")	Teachable	■	■			■	■		+/- 6.35mm (0.25") default window
VM18-NPI1000-Q	■		■	508 mm (20")	Teachable	■		■	■		■		+/- 12.7mm (0.50") default window
VM18-NPO1000-Q	■		■	508 mm (20")	Teachable	■		■	■		■		+/- 12.7mm (0.50") default window
VM18-PPI1000-Q	■		■	508 mm (20")	Teachable	■		■	■	■	■		+/- 12.7mm (0.50") default window
VM18-PPO1000-Q	■		■	508 mm (20")	Teachable	■		■	■	■	■		+/- 12.7mm (0.50") default window
VM18-NPI1001-Q	■		■	508 mm (20")	Teachable	■		■	■		■		+/- 6.35mm (0.25") default window
VM18-NPO1001-Q	■		■	508 mm (20")	Teachable	■		■	■		■		+/- 6.35mm (0.25") default window
VM18-PPI1001-Q	■		■	508 mm (20")	Teachable	■		■	■	■	■		+/- 6.35mm (0.25") default window
VM18-PPO1001-Q	■		■	508 mm (20")	Teachable	■		■	■	■	■		+/- 6.35mm (0.25") default window

Temperature Compensation is enabled by default.
All possible sensor configurations are not listed here.